

BOTTOM LATCH ASSEMBLY & STRIKE TEMPLATE

- (1) 1 cutting hole(b) for strike :
 $1\text{-}1/2''[38.1] \times 1\text{-}1/2''[38.1]$ cut $1''[25]$ deep by template.
- (2) 2 mounting holes(a) for latch assembly :
 $\varnothing 3/8''[\varnothing 9.5]$ drill thru by template.

NOTE:

1. Align template along center line (marking on door), tape to door and finished floor as an aid to cut holes.
2. Before cutting holes, check door is on closing position.
3. This side is for LHR door application, RHR door see another side.

Tape this side to door

LHR DOOR

Tape this side to frame

FOLD OUT HERE

ALONG
BACKSET
LINE

