

TOP LATCH ASSEMBLY & STRIKE TEMPLATE

Tape this side to frame

LHR DOOR

Tape this side to door

FOLD OUT HERE

- (1) 3 mounting holes(a,a') for strike :
Dia.#17[Ø3.8] drill 1-1/8"[28] deep , #12U24 (unnecessary for wood) tap 1"[25] deep .
Drilling (a) by template , install strike and adjust as need , then drilling (a') by strike .
- (2) 2 mounting holes(b) for latch assembly :
Ø3/8"[Ø9.5] drill thru by template.

NOTE:

- 1.Align template along center line(marking on door) , tape to door and frame as an aid to cut holes.
- 2.Before cutting holes , check door is on closing position.
- 3.This side is for LHR door application , RHR door see another side.

Rev : 06/2023

