


11.65*34.8

FOR ALUMINUM DOORS

Concealed Panic Exit Devices

LOCK STILE INSIDE FACE



12.1*27.9

FOR ALUMINUM DOORS

Concealed Panic Exit Devices

HINGE STILE
INSIDE FACE

FOLD DOWN ALONG THIS LINE AND PLACE AGAINST DOOR JAMB — **RHRB DOOR**

FOLD DOWN ALONG THIS LINE AND PLACE AGAINST DOOR JAMB — **LHRB DOOR**

39-17/32"
BOTTOM OF
STILE TO
THIS LINE



39-17/32"
BOTTOM OF
STILE TO
THIS LINE



DRILL AND TAP 12-24 (2)



FOR ALUMINUM DOORS


Concealed Panic Exit Devices

LOCK STILE
OUTSIDE FACE

FOLD DOWN ALONG THIS LINE AND PLACE AGAINST DOOR JAMB — *RHRB DOOR*

FOLD DOWN ALONG THIS LINE AND PLACE AGAINST DOOR JAMB — *LHRB DOOR*

NOTE: FOR KEY CYLINDER ONLY
DRILL 1-3/16" CYLINDER HOLE




39-17/32"
BOTTOM OF
STILE TO
THIS LINE

39-17/32"
BOTTOM OF
STILE TO
THIS LINE



Modern • Flat Touch Bar • Concealed Vertical Rod • Panic Exit Device

ALUMINUM STOREFRONT DOORS LHRB DOOR SHOWN (RHRB OPPOSITE)



- TO CHANGE HAND OF PANIC TO RHRB**
1. After you change hand of panic to RHRB, Remove screw holding crank in Mechanism.
 2. Position opposite crank in Mechanism and make sure that Link fits over end Pin, Insert screw in Mechanism and tighten.